

TRIANGULAR SHOWER DRAIN


SKU# KTD165-PIXELGRATE | KTD165-TILEGRATE



KUBE BATH
AFFORDABLE LUXURY FOR YOUR BATHROOM


TOP ELEVATION

Stainless Steel Grate and Matte Black




FRONT ELEVATION

Stainless Steel Grate and Matte Black



EXPLODED VIEW



1. Shower Drain Grate
2. Protective Drain Membrane
3. Adjustment Screw
4. Adjustable Grate Support
5. Gutter rough-in
6. Grate Hook
7. Allen Key

CARE AND CLEANING OF YOUR DRAIN

Mild dishwashing liquids will keep the surfaces bright and clean. Rinse well and dry with a clean cloth.

Caution:

Powder detergent and liquid abrasive cleaners may damage surfaces. Do not allow visible surfaces to come into contact with corrosive products such as drain cleaners.

DO NOT USE:

- Cleaning agents that contains chlorides, alcohol, ammonia or mineral spirits.
- Steel wool, scouting pad or wire brushes.

TRIANGULAR SHOWER DRAIN

INSTALLATION INSTRUCTIONS

NOTES BEFORE INSTALLATION

Read the following instructions carefully. Observe all local plumbing and building codes.

INSTRUCTIONS

For the following instructions, it is assumed that the shower pan and drain flange coupling are already in place. Your application and conditions may call for variations of these procedures. Kubebath accepts no liability for any damage to floor, walls, plumbing, etc... or for personal injury during installation. We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures and plumbing.

TOOLS AND MATERIALS



Silicon Sealant



Level



Thinset Mortar




Pea Gravel
(32 ounces)


INSTALLATION



1. Insert the rubber drain gasket into the drain flange coupling.



2. Insert the drain outlet into the rubber gasket and place in the desired position. Adjust or remove the drain feet if necessary.




3. Place pea gravel over the drain flange coupling weep holes and around the perimeter to prevent mortar from filling and blocking the holes.



4. Apply mortar over the waterproof shower pan liner, starting from the drain and continuing to the wall. Using a level, create a 1-2° slope from the wall to the drain.



5. Allow mortar to cure.



6. Once the tiling and grouting are complete, apply a thin bead of silicone sealant around the drain to fill any gaps between the drain and tile.

Note: Be sure to leave the room for final thinset and tile application.


The top of the drain should be leveled and 0.063" below adjacent tile.

UNION FITTING INSTALLATION


HTBATH

AFFORDABLE LUXURY FOR YOUR BATHROOM

1. 2x6 wood
2. Subfloor
3. Wall
4. Waste Pipe
5. Union Fitting
6. Gutter Rough-in
7. Adjustable Grate
8. Shower Drain Grate
9. Strainer
10. Gypsum
11. Mortar Bed
12. Textile Membrane
13. Protective Drain Membrane
14. Cement Glue
15. Grout
16. Ceramic tiles



The drain can be installed in many configurations. However, the pan should have 1 to 4% drainage slope towards the drain.




TRIANGULAR SHOWER DRAIN

INSTALLATION GUIDE


KUBE BATH
AFFORDABLE LUXURY FOR YOUR BATHROOM

1. CUT THE SUBFLOOR




Approximate measurement for 0.375" (10mm) thick ceramic.
Provide space for the grout between the flange and the wall.


2. SET DRAIN AND TIGHTEN THE COUPLING



3. CONNECTION LINK TEST



4. INSTALL GYPSUM




TRIANGULAR SHOWER DRAIN

INSTALLATION GUIDE


KUBE BATH

AFFORDABLE LUXURY FOR YOUR BATHROOM


5. SLOPE SURFACE




6. INSTALL MEMBRANE



7. SEAL THE JOINTS




8. GLUE THE PROTECTIVE DRAIN MEMBRANE



TRIANGULAR SHOWER DRAIN


INSTALLATION GUIDE

9. MEMBRANE LEAK TEST





Block the hole of the drain and check underneath the subfloor to ensure that the membrane is waterproof


10. ADJUSTING THE GRATE



Remove the grate




Align the grate with the tiles




Adjust the grate support

11. TILING



12. JOINT CEMENT AND CLEANING



Do not fill up the drain entry